ACCUSPLIT

PRO SURVIVOR

STOPWATCH

STOPWATCH OPERATIONS
For Typical Uses

Press C until at STOPWATCH display.
If necessary, Press R to Stop and L to Reset to zero.

Event	Split	1-2 Finish
R-Start	R-Start	R-Start
R-Stop	L-Split	L-Stop #1
(Repeat R,R time-in/ time-out)	L-Release (Repeat L,L each Split)	R-Stop #2 (See #1 time)
L-Reset	R-Stop	L-Release
	L-Reset	(See #2 time)
		L-Reset

TIME AND CALENDAR DISPLAY
-Press C, until at TIME display.
-Hold R–display Month, Date and PM indicator (P).
-Hold L–display MEMO TIME (Professional X Stopwatch Series do not have Sound Alarm or Chime).



TO SET TIME AND CALENDAR
-Hold C for 3 seconds and Press C once to enter TIME SET MODE.
-Press R to select Minutes, Hour, Month, Date, Day, Seconds.
-Press L to change any of the above. (Seconds only resets to 00). (Hold L to change digits rapidly).
-Press C to return to TIME display.

TO SET MEMO TIME
-Hold C for 3 seconds to enter MEMO TIME SET MODE.
-Press R to select Minutes and Hours.
-Press L to change Minutes and Hours.
-Press C to return to TIME display.

TO SET 12/24 HOUR FORMAT
-Hold R and Press C to interchange 12P or 24 format.

BATTERY CHANGING
See Specifications panel.

NO-PROOF-OF-PURCHASE LIMITED WARRANTY
See label on back of unit for details, or check
http://support.ACCUSPLIT.com

ACCUSPLIT, Inc. • 3090 Independence Drive, Suite 148 • Livermore, CA 94551 USA
800-935-1996 • 925-290-1900 • FAX 925-290-1930 • www.ACCUSPLIT.com • support@ACCUSPLIT.com

repair@accusplit.com
www.accusplit.com

ASSEMBLED IN PRCHINA

© 2004 ACCUSPLIT